Силовой агрегат

Land Rover Discovery Sport (L550) · Руководство по ремонту
Источник: lrdisc.com · разделов: 1

Содержание

1. Силовой агрегат

Силовой агрегат

Powertrain

- Acceleration and Speed Control
    1. Accelerator Pedal (G1350481) / Removal and Installation
    2. Speed Control
- Automatic Transmission Transaxle
    1. External Controls Transmission Control Switch
    2. External Controls
    3. Automatic Transmission Transaxle / Description and operation
    4. Automatic Transmission Transaxle/ Diagnosis and Testing
    5. Four-wheel Drive Systems - Vehicles With
    6. Main Control Valve Body Solenoids (G1948467) / Removal and Installation
    7. Main Control Valve Body Solenoids (G1948467) / Removal and Installation
    8. Selector Shaft Seal - Ingenium i4 2.0l Diesel (G1894392) / Removal and Installation
    9. Torque Converter - Ingenium i4 2.0l Diesel (G1894240) / Removal and Installation
    10. Torque Converter Seal - Ingenium i4 2.0l Diesel (G1894394) / Removal and Installation
    11. Transmission - Ingenium i4 2.0l Diesel (G1887785) / Removal
    12. Transmission - Ingenium i4 2.0l Diesel (G1887786) / Installation
    13. Transmission Cover (G1780374) / Removal and Installation
    14. Transmission Fluid Drain and Refill (G1660818) / General Procedures
    15. Transmission Fluid Level Check (G1660817) / General Procedures
    16. Transmission Fluid Pan - Ingenium i4 2.0l Diesel (G1894395) / Removal and Installation
    17. Transmission Oil Supply Pipe (G1707722) / Removal and Installation
    18. Transmission Transaxle Cooling Description and Operation
- Engine
    1. Accessory Drive
    2. Electronic Engine Controls - Ingenium i4 2.0l Diesel
    3. Electronic Engine Controls - Ingenium i4 2.0l Diesel
    4. Electronic Engine Controls - Ingenium i4 2.0l Diesel / Diagnosis and Testing
    5. Engine - Ingenium i4 2.0l Diesel
    6. Cylinder Head Gasket (G1875895)
    7. Engine - Ingenium i4 2.0l Diesel Engine (G1880413) / (G1880415)
    8. Engine - Ingenium i4 2.0l Diesel Engine and Ancillaries
    9. Engine Front Cover (G1875898) / Removal and Installation
    10. Engine Mount (G1913572) / Removal and Installation

11. Engine - Ingenium i4 2.0l Diesel Engine Mount Alignment (G1815586) / General Procedures
12. Engine - Ingenium i4 2.0l Diesel Engine Oil Draining and Filling (G1875867) / General Procedures
13. Engine - Ingenium i4 2.0l Diesel Engine Oil Vacuum Draining and Filling (G2008758)/ General Procedures
14. Engine - Ingenium i4 2.0l Diesel Engine Upper Support Insulator (G1923644) / Removal and Installation
15. Engine - Ingenium i4 2.0l Diesel Flexplate (G1875884) / Removal and Installation
16. Engine - Ingenium i4 2.0l Diesel Flywheel (G1875896) / Removal and Installation
17. Engine - Ingenium i4 2.0l Diesel Intake Manifold (G1875868) / Removal and Installation
18. Engine - Ingenium i4 2.0l Diesel Lower Timing Chain (G1875890)
19. Engine - Ingenium i4 2.0l Diesel Lower Timing Cover (G1875873) / Removal and Installation
20. Engine - Ingenium i4 2.0l Diesel Oil Cooler (G1875880) / Removal and Installation
21. Engine - Ingenium i4 2.0l Diesel Oil Pan (G1875878) / Removal and Installation
22. Engine - Ingenium i4 2.0l Diesel Oil Pump (G1875879) / Removal and Installation
23. Engine - Ingenium i4 2.0l Diesel Upper Timing Chain (G1875889)
24. Engine - Ingenium i4 2.0l Diesel Upper Timing Cover (G1875872) / Removal and Installation
25. Engine - Ingenium i4 2.0l Diesel Valve Cover (G1875874)
26. Engine - Ingenium i4 2.0l Diesel Valves (G1875887) / Removal and Installation
27. Engine - Ingenium i4 2.0l Diesel / Description and Operation
28. Engine - Ingenium i4 2.0l Diesel / Diagnosis and Testing
29. Engine Cooling - Ingenium i4 2.0l Diesel Charge Air Radiator (G1879559) / Removal and Installation
30. Engine Cooling - Ingenium i4 2.0l Diesel Coolant Pump (G1879556) / Removal and Installation
31. Engine Cooling - Ingenium i4 2.0l Diesel Cooling Fan Motor and Shroud (G1879558)/ Removal and Installation
32. Engine Cooling - Ingenium i4 2.0l Diesel Cooling System Concentration Check (G2154751) / General Procedures
33. Engine Cooling - Ingenium i4 2.0l Diesel Cooling System Draining, Filling and Bleeding (G1879552) / General Procedures
34. Engine Cooling - Ingenium i4 2.0l Diesel Cooling System Partial Draining and Vacuum Filling (G1809493) / General Procedures
35. Engine Cooling - Ingenium i4 2.0l Diesel Cooling System Partial Draining, Filling and Bleeding (G1879553) / General Procedures
36. Engine Cooling - Ingenium i4 2.0l Diesel Cooling System Pressure Test (G1898875) / General Procedures
37. Engine Cooling - Ingenium i4 2.0l Diesel Radiator (G1879557) / Removal and Installation
38. Engine Cooling - Ingenium i4 2.0l Diesel Thermostat (G1879555) / Removal and Installation
39. Engine Cooling - Ingenium i4 2.0l Diesel / Description and Operation
40. Engine Cooling - Ingenium i4 2.0l Diesel / Diagnosis and Testing
41. Engine Emission Control - Ingenium i4 2.0l Diesel Diesel Exhaust Fluid Filler Assembly (G1875908) / Removal and Installation
42. Engine Emission Control - Ingenium i4 2.0l Diesel Diesel Exhaust Fluid Injector (G1875907) / Removal and Installation
43. Engine Emission Control - Ingenium i4 2.0l Diesel Diesel Exhaust Fluid Level Check and top-up (G1979040) / General Procedures
44. Engine Emission Control - Ingenium i4 2.0l Diesel Diesel Exhaust Fluid Pipe (G1875910) / Removal and Installation
45. Engine Emission Control - Ingenium i4 2.0l Diesel Diesel Exhaust Fluid Tank Drain and Refill (G1875905) / General procedures

46. Engine Emission Control - Ingenium i4 2.0l Diesel High Pressure Exhaust Gas Recirculation Cooler (G2162458) / Removal and Installation
47. Engine Emission Control - Ingenium i4 2.0l Diesel High Pressure Exhaust Gas Recirculation Valve (G1875913) / Removal and Installation
48. Engine Emission Control - Ingenium i4 2.0l Diesel Low Pressure Exhaust Gas Recirculation Cooler (G1875912) / Removal and Installation
49. Engine Emission Control - Ingenium i4 2.0l Diesel Low Pressure Exhaust Gas Recirculation Valve (G1875911) / Removal and Installation
50. Engine Emission Control - Ingenium i4 2.0l Diesel / Description and Operation
51. Engine Emission Control - Ingenium i4 2.0l Diesel / Diagnosis and Testing
52. Engine System - General Information Bearing Inspection (G61255) / General Procedures
53. Engine System - General Information Cylinder Compression Test - Ingenium i4 2.0l Diesel (G1817137) / General Procedures
54. Engine System - General Information Leakage Test Using Smoke Test Equipment (G1445299) / General Procedures
55. Fuel Charging and Controls - Ingenium i4 2.0l Diesel Fuel Injection Component Cleaning (G1202495)
56. Fuel Charging and Controls - Ingenium i4 2.0l Diesel Fuel Injector Fuel Return Line (G1875962)
57. Fuel Charging and Controls - Ingenium i4 2.0l Diesel Fuel Injectors (G1875958) / Removal and Installation
58. Fuel Charging and Controls - Ingenium i4 2.0l Diesel Fuel Pump (G1875960)
59. Fuel Charging and Controls - Ingenium i4 2.0l Diesel Fuel Rail (G1875959)
60. Fuel Charging and Controls - Ingenium i4 2.0l Diesel Throttle Body (G1875961) / Removal and Installation
61. Fuel Charging and Controls - Ingenium i4 2.0l Diesel / Description and Operation
62. Fuel Charging and Controls - Ingenium i4 2.0l Diesel / Diagnosis and Testing
63. Fuel Charging and Controls - Turbocharger - Ingenium i4 2.0l Diesel Turbocharger (G1875964) / Removal and Installation
64. Fuel Charging and Controls - Turbocharger - Ingenium i4 2.0l Diesel Turbocharger Oil Return Hose (G1875965) / Removal and Installation
65. Fuel Charging and Controls - Turbocharger - Ingenium i4 2.0l Diesel Turbocharger Oil Supply Tube (G1875966) / Removal and Installation
66. Fuel Charging and Controls - Turbocharger - Ingenium i4 2.0l Diesel / Description and Operation
67. Glow Plug System - Ingenium i4 2.0l Diesel Glow Plug Module (G1999588) / Removal and Installation
68. Glow Plug System - Ingenium i4 2.0l Diesel / Description and Operation
69. Glow Plug System - Ingenium i4 2.0l Diesel / Diagnosis and Testing
70. Intake Air Distribution and Filtering - Ingenium i4 2.0l Diesel Air Cleaner (G1877886)/ Removal and Installation
71. Intake Air Distribution and Filtering - Ingenium i4 2.0l Diesel Charge Air Cooler (G1875919) / Removal and Installation
72. Intake Air Distribution and Filtering - Ingenium i4 2.0l Diesel / Description and Operation
73. Intake Air Distribution and Filtering - Ingenium i4 2.0l Diesel / Diagnosis and Testing
74. Starting System - Ingenium i4 2.0l Diesel Starter Motor (G1879568) / Removal and Installation
75. Starting System - Ingenium i4 2.0l Diesel / Description and Operation
76. Starting System - Ingenium i4 2.0l Diesel / Diagnosis and Testing

- Exhaust System
    1. Exhaust - Ingenium i4 2.0l Diesel Catalytic Converter (G1880489)

2. Exhaust - Ingenium i4 2.0l Diesel Catalytic Converter to Turbocharger Clamp (G1964846)/ Removal and Installation
3. Exhaust - Ingenium i4 2.0l Diesel Diesel Particulate Filter - System Operation and Component Description
4. Exhaust - Ingenium i4 2.0l Diesel Diesel Particulate Filter - Vehicles With- Diesel Exhaust Fluid (G1880492) / Removal Installation
5. Exhaust - Ingenium i4 2.0l Diesel Diesel Particulate Filter - Vehicles Without- Diesel Exhaust Fluid (G1887685) / Removal Installation
6. Exhaust - Ingenium i4 2.0l Diesel Diesel Particulate Filter / Diagnosis and Testing
7. Exhaust - Ingenium i4 2.0l Diesel Rear Silencer (G2142885) / Removal and Installation
8. Exhaust - Ingenium i4 2.0l Diesel / Description and Operation
9. Exhaust - Ingenium i4 2.0l Diesel Exhaust System DTC- Selective Catalytic Reduction (SCR) / Diagnosis and Testing
10. Exhaust - Ingenium i4 2.0l Diesel Selective Catalyst Reduction / Diagnosis and Testing

- Fuel System

1. Fuel Filter (G1879979) / Removal and Installation
2. Fuel Tank and Lines - Ingenium i4 2.0l Diesel Fuel Cooler (G1885493)
3. Fuel Tank and Lines - Ingenium i4 2.0l Diesel Fuel Pump and Sensor Unit (G1779691)
4. Fuel Tank and Lines - Ingenium i4 2.0l Diesel Fuel Tank (G1779692) / Removal and Installation
5. Fuel Tank and Lines - Ingenium i4 2.0l Diesel / Description and Operation
6. Fuel Tank and Lines - Ingenium i4 2.0l Diesel Diagnosis and Testing
7. Fuel Tank Draining (G898063) / General Procedures

- Manual Transmission Transaxle and Clutch

1. Clutch / Description and Operation
2. Clutch System Bleeding (G1353044) / General Procedures
3. Four-Wheel Drive Systems - Vehicles With- Active Driveline / Description and Operation
4. Four-Wheel Ddrive Systems - Vehicles Without- Active Driveline / Description and Operation
5. Gearshift Cable Adjustment
6. Manual Transmission Transaxle Left Halfshaft Seal (G1353054) / Removal and Installation
7. Manual Transmission Transaxle Transmission Fluid Level Check (G2162887) / General Procedures
8. Manual Transmission Transaxle / Description and Operation
9. Manual Transmission - Transaxle / Diagnosis and Testing
10. Manual Transmission Transaxle External Controls Gearshift Cables (G1779360) / Removal and Installation
11. Manual Transmission - Transaxle External Controls Gearshift Lever (G1781378) / Removal and Installation
12. Manual Transmission - Transaxle External Controls Gearshift Linkage (G1781377) / Removal and Installation
13. Manual Transmission - Transaxle External Controls / Description and Operation
14. Transfer Case - M66 6-Speed Manual AWD- 9HP48 9-Speed Automatic

ne

Front Turn Signal Lamp Bulb (G1785540) Removal and InstallationAcceleration and Speed Control

ne